

## ANNEX: Winter Installation with Spacer Tool Wall Cladding – Board & Batten Edition

### Board & Batten:

- Please use the spacing tool provided with your order to maintain the minimum required space when temperatures drop below 5 degrees Celsius.
- Space the boards apart using the aluminum guide as shown in the following illustrations.
- Spacing of 1.3 MM.



Starting  
Trim



Install the first board as indicated in the installation guide and fix it to the building using Fiberwood screws.

Fastening strip  
side (nailing)

Side of the  
board



Use the spacing guide provided by Fiberwood (2 guides included). Be aware that it has a longer edge that should be used on the side where the boards interlock with each other.

**4** Installation of the guide on the trim.

**5** Install the guides to level the next board.

**6** Insert the next board and simply rest it against the guides.

Longer side of the guide



The tool is designed to create a space of approximately 1.3 mm during installations performed in cold weather (5 degrees Celsius or below) to allow for expansion during the summer season.

Once the new board is properly fixed, remove the guides and repeat the process to install the remaining boards.